

 applied system technologies™ Optimum Performance			
		Rev: 2	Date: 1/18/2016
INSTALLATION INSTRUCTIONS		Page 1 of 1	
TITLE: Quick-Fit Piping System – Installation Instructions			

Purpose: This document covers the installation instructions for the **Quick-Fit piping system** supplied through Applied System Technologies

Scope: This document covers the Infinity piping range, specifically sizes **14mm**

Instructions:

1. Cut tube to proper length for the installation. The cut must be clean and square. Use a proper tube cutter (no hacksaw).
2. Deburr pipe outside diameter (OD) on each end to prevent any damage to the o-ring seal during assembly.
3. Mark the tube 7/8" back from the end that is to be inserted into the fitting.
4. To install the pipe, push and rotate the pipe into the fitting until fully seated up to the mark. Repeat for each tube/fitting insertion.

Tube Removal:

Ensure system is at zero pressure!!

While pushing and holding the black plastic tube guide into the fitting, push the tube into the fitting to release the retainers then pull the tube out. The fitting may be reused as required

For further clarification on this requirement please call
Applied System Technologies – 704-947-6966

REV.	DESCRIPTION OF CHANGE	DATE	APPROVALS	
			President	QA
0	Initial Release	n/a	PA	DAP
1	Layout changes only	1-18-12	PA	n/a
2	Layout changes only	1/18/16	ML	TZ